

**VERSUS** 



## The facts:

	radarTOUCH	radarTOUCH LT
	Including Hardware:	Including Hardware:
01	USB dongle radarTOUCH	USB dongle radarTOUCH LT
02	power cable	power cable
03	mains adapter	mains adapter
04	Ethernet cable	Ethernet cable
05	RS232 cable	RS232 cable
06	Standard mounting system	
	Software functions:	Software functions:
07	startMinimised	startMinimised
08	wideWorkingRange	wideWorkingRange
09	minObjectSizeIs_1	minObjectSizeIs_1
10	flipXandY	flipXandY
11	Blob reduction	Blob reduction
12	mouseVersion1	mouseVersion1
13	mouseVersion2	
14	mouseVersion3	
15	allowStartingTwice	
16	radarDROIDactive	
17	radarTRACK	
18	Number of simultaneous active areas: 10	Number of active areas: 1

## What does that mean?

- 06 If you buy the LT version you would have to buy a mounting system separately if desired. More information regarding mounting systems you will find in the radarTOUCH manual at chapter 3.1
- 13 + 14 The LT version includes only one mouse version, it keeps the left mouse button clicked as long as an obstacle (e.g. hand or finger) stays in the active area. If the system detects two obstacles, it scrolls the mouse wheel up or down depending on a changing distance between the two obstacles. With this, some sort of zoom gesture can be used. More information regarding mouse versions are written in chapter 4.3.2 in the radarTOUCH manual.
- radarTOUCH LT cannot be started twice on one PC. If you need more than one system running on one PC you need the full version.
- you can't use the radarDROID app with the LT version. If you want to control the radarTOUCH driver with an android device you need the full version
- 17 If you buy radarTOUCH full version you will get the radarTRACK software extension for free. If you buy radarTOUCH LT there is no additional software extension included.
- 18 With radarTOUCH LT you can send the TUIO data just to one IP address and port

